



MAINTENANCE PARTS LIST FOR SFC BURNER

In order to keep the combustion equipment in the best condition, we recommend the following parts for periodic replacement.

List of Periodic Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
1	ATOMIZER	Once a Year	
2	CAP NUT		
3	PILOT ATOMIZER		
4	IGNITON ELECTRODE		
5	SWIRLER		
6	SENSOR FOR FLAME EYE (PHOTO CELL)		
7	OIL SEAL FOR PUMP		
8	COUPLING RUBBER		
9	GLAND PACKING OF SPRAYER		
10	GASKET OF SPRAYER		
11	PACKING OF SPRAYER		
12	SPRING OF SPRAYER		
13	PLUG OF SPRAYER		
14	GUIDE RING SEAL PACKING		
15	SECONDARY SWIRLER	Once every 3 years	
16	FLEXIBLE HOSE		
17	PRESSURE GAUGE		
18	COMPOUND GAUGE		
19	COUPLING FOR PUMP/MOTOR		
20	BEARING FOR MOTOR		
21	BASKET FOR STRAINER		
22	O RING FOR STRAINER		
23	COUPLER		

Please turn over.

List of Periodic Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
24	SPRAYER	Once every 5 years	
25	IGNITION TRANSFORMER		
26	FLAME DETECTOR RELAY		
27	LIMIT SWITCH(SPRAYER INSERT)		
28	LIMIT SWITCH(SECONDARY DAMPER)		
29	SOLENOID VALVE FOR PILOT BURNER		
30	PILOT BURNER		
31	3-PORT SOLENOID VALVE		

*Earlier replacement may be needed depending on the operating condition.

*Parts other than those listed above also need to be replaced depending on the condition.

Please contact Japanese trading company to obtain a quotation for spare parts along with this check list.

In case you do not have business with Japanese trading company, please email us to

"info-m@volcano.co.jp".

We will send you contact details of the trading company by return.