



MAINTENANCE PARTS LIST FOR VJ BURNER

In order to keep the combustion equipment in the best condition, we recommend the following parts for periodic replacement.

List of Periodic Replacement Parts			
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED
1	F.O. ATOMIZER	Once a Year	
2	CAP NUT		
3	IGNITION ELECTRODE		
4	STABILIZER		
5	SENSOR FOR FLAME EYE (PHOTO CELL)		
6	OIL SEAL FOR PUMP		
7	COUPLING RUBBER		
8	IGNITION PLUG	Once every 3 years	
9	METAL THROAT		
10	BEARING FOR MOTOR		
11	COIL FOR MAGNETIC VALVE		
12	COUPLING FOR PUMP / MOTOR		
13	PRESSURE GAUGE		
14	COMPOUND GAUGE		
15	THERMOMETER		
16	OIL STRAINER or STRAINER BASKET		

Please turn over.

List of Periodic Replacement Parts				
No	ITEM	STANDARD RENEWAL TERM	QUOTATION REQUIRED	
17	ATOMIZER BLOCK	Once every 5 years		
18	PUMP			
19	RELIEF VALVE			
20	FLAME EYE			
21	FLAME DETECTOR RELAY			
22	MAGNETIC VALVE			
23	DAMPER SOLENOID			
24	IGNITION TRANSFORMER			
25	IGNITION CABLE			
26	CONTROL PANEL TRANSFORMER			
27	SWITCHING POWER SUPPLY			
28	BATTERY FOR PLC			
29	MAGNETIC SWITCH with THERMAL RELAY			
30	AUXILIARY RELAY			
31	HEATER ELEMENT			
32	THERMOSTAT			
33	PRESSURE SWITCH			
34	SEQUENCER (PLC)		Once every 7 ~ 8 years	
35	MOTOR			

*Earlier replacement may be needed depending on the operating condition.

*Parts other than those listed above also need to be replaced depending on the condition.

Please contact Japanese trading company to obtain a quotation for spare parts along with this check list.

In case you do not have business with Japanese trading company, please email us to

"info-m@volcano.co.jp".

We will send you contact details of the trading company by return.