



Recommended parts for Slow-steam [MJII burner]

<p>1. Burner head part</p> <p style="margin-left: 20px;">a. Burner head assy (include below eight items)</p> <p style="margin-left: 40px;">Sprayer</p> <p style="margin-left: 40px;">Atomizer</p> <p style="margin-left: 40px;">Cap nut</p> <p style="margin-left: 40px;">Coupler</p> <p style="margin-left: 40px;">Swirler</p> <p style="margin-left: 40px;">Pilot burner</p> <p style="margin-left: 40px;">Pilot atomizer</p> <p style="margin-left: 40px;">Ignition electrode</p> <p style="margin-left: 20px;">b. Metal throat</p> <p style="margin-left: 20px;">c. Flexible hose</p> <p>2. Flame-eye part</p> <p style="margin-left: 20px;">a. Flame-eye</p> <p style="margin-left: 20px;">b. Flame detector relay</p> <p>3. F.O. pump part</p> <p style="margin-left: 20px;">a. F.O. pump</p> <p style="margin-left: 20px;">b. Coupling</p> <p style="margin-left: 20px;">c. Motor for F.O. pump</p> <p style="margin-left: 20px;">d. Ball bearing for above motor</p> <p style="margin-left: 20px;">e. Pressure gauge</p> <p style="margin-left: 20px;">f. Compound gauge</p> <p>4. D.O. (Pilot) pump part</p> <p style="margin-left: 20px;">a. D.O. pump</p> <p style="margin-left: 20px;">b. Coupling</p> <p style="margin-left: 20px;">c. Motor for D.O. pump</p> <p style="margin-left: 20px;">d. Ball bearing for above motor</p> <p style="margin-left: 20px;">e. Pressure gauge</p> <p style="margin-left: 20px;">f. Compound gauge</p>	<p>5. Piping part</p> <p style="margin-left: 20px;">a. F.O. inlet magnetic valve</p> <p style="margin-left: 20px;">b. Pressure switch</p> <p style="margin-left: 20px;">c. Transmitter for F.O. pressure</p> <p style="margin-left: 20px;">d. Oil pressure adjusting valve</p> <p style="margin-left: 20px;">e. Pressure gauge</p> <p>6. Oil heater part</p> <p style="margin-left: 20px;">a. Heater element assy (include below four items)</p> <p style="margin-left: 40px;">Heater element</p> <p style="margin-left: 40px;">Thermostat</p> <p style="margin-left: 40px;">Burner terminal box</p> <p style="margin-left: 40px;">Heater flange packing</p> <p style="margin-left: 20px;">b. Resistance bulb</p> <p>7. Air inlet part</p> <p style="margin-left: 20px;">a. Air damper solenoid</p> <p style="margin-left: 20px;">b. Motor for F.D. fan</p> <p style="margin-left: 20px;">c. Bearing for above motor</p> <p>8. Igniter power source part</p> <p style="margin-left: 20px;">a. Ignition transformer</p> <p style="margin-left: 20px;">b. Secondary cable</p> <p>9. Control panel part</p> <p style="margin-left: 20px;">a. F.O. temp controller</p> <p style="margin-left: 20px;">b. Aux. relay</p> <p style="margin-left: 20px;">c. Transformer</p> <p style="margin-left: 20px;">d. Fuse</p> <p style="margin-left: 20px;">e. Main switch</p> <p style="margin-left: 20px;">f. Magnetic switch</p> <p style="margin-left: 20px;">g. Switching power supply</p> <p style="margin-left: 20px;">h. Sequencer/PLC</p> <p style="margin-left: 20px;">i. Exhaust gas temperature relay</p> <p style="margin-left: 20px;">j. Timer</p>
---	--

Contact VOLCANO (on Products, Parts and After-sales service)

Combustion Engineering Division
VOLCANO Co., Ltd.

info-m@volcano.co.jp
FAX +81 6 6396 7609 TEL +81 6 6392 5541
<http://www.volcano.co.jp/>
1-3-38, Nonaka-kita, Yodogawa-ku, Osaka
532-0034 Japan